


Gtech

Leaf Blower

Model number: LB01



OPERATING MANUAL

IMPORTANT SAFEGUARDS:



**IMPORTANT: READ ALL INSTRUCTIONS BEFORE USE.
RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.**



Do not use in rain or leave outdoors whilst raining.



WARNING: Basic safety precautions should always be observed when using an electrical appliance to reduce the risk of fire, electrical shock or serious injury.

Personal Safety:

- Only use the leaf blower in the manner intended and as described in this manual.
- Keep out of reach of children and animals at all times.
- Only use in daylight or good artificial light.
- Always be sure of your footing on uneven ground, slopes or in slippery conditions.
- Do not over-reach or use on excessive steep slopes.
- Remove any stones, loose debris and other objects from the area.
- Pay special attention to the hazards posed to bystanders by thrown or flyaway objects.
- Stay alert, watch what you are doing and use common sense when operating a power tool.
- Do not use power tools while you are tired or under the influence of drugs, alcohol or medication. This may result in serious personal injury.
- Always be aware of your surroundings and stay alert for possible hazards.
- Use protective personal equipment such as safety glasses, non-skid safety shoes, sturdy gloves to reduce the risk of personal injury.
- Do not operate when barefoot or wearing open toed shoes. Always wear substantial footwear and long trousers.
- Dress appropriately. Do not wear loose clothing or jewellery and keep hair, clothing and gloves away from moving parts.
- Avoid accidental starting. Ensure the trigger is off whilst picking up or carrying the product.
- Do not run with the leaf blower.
- When operating the leaf blower ensure that hands are correctly positioned on the handle.
- Do not operate the leaf blower if it is incomplete or has unauthorised modifications.
- Keep all body parts, especially hands and feet, away from the motor at all times.
- Ensure that the motor has fully stopped before cleaning, clearing a blockage, checking, or carrying out maintenance on the leaf blower.
- Carry the leaf blower by the handle.
- The operator is responsible for accidents or hazards occurring to other people at their property.
- Never operate the leaf blower if it is damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience or knowledge.
- Keep the product and all accessories

away from hot surfaces.

- Never modify the leaf blower in any way.

Electrical safety:

- Do not operate the leaf blower in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. The motor may create sparks, which may ignite the dust and fumes.
- Do not use the leaf blower when a thunderstorm is approaching.
- Avoid body contact with earthed or grounded surfaces, such as pipes. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose the leaf blower to rain or wet conditions.
- Do not handle the charger or the leaf blower with wet hands.
- Before charging check the power supply and charger cables for signs of damage or ageing.
- For safety the leaf blower will automatically cut out if the motor becomes overheated. If this occurs, wait a few seconds for the cut out to reset and then use again.

Battery safety:

- Do not attempt to use the charger with any other product or to charge this product with any other charger.
- This product contains Li-Ion batteries. Do not incinerate batteries or expose to high temperatures, as they may explode.
- Do not charge the battery when the surrounding air temperature or the battery pack is below 0°C or above 45°C.

- After heavy use or in high temperatures the battery may become warm. Allow the product to cool for 30 minutes before charging.
- Use only with the battery pack supplied.
- Leaks from battery cells can occur under extreme conditions. If the liquid gets on your skin wash immediately with soap and water. If the liquid gets into your eyes, flush them immediately with cold water for a minimum of 10 minutes and seek urgent medical attention.
- Do not store the battery outside for prolonged periods of time, especially over the winter months.

Training

- Read the instructions carefully. Be familiar with the controls and the correct use of the machine.
- Never allow children or people unfamiliar with these instructions to use the machine. Local regulations can restrict the age of the operator.
- Keep in mind that the operator or user is responsible for accidents or hazards occurring to other people or their property.

Preparation

- Before use, always visually inspect the machine for damaged, missing or misplaced guards or shields.
- Never operate the machine while people, especially children, or pets are nearby.

Operation

- Wear eye protection and stout shoes at all times while operating the machine.
- Avoid using the machine in bad weather conditions especially when there is a risk of lightning.
- Never operate the machine if damaged.
- Switch on the motor only when pointed in the desired direction.
- Always disconnect the machine from the power supply (removable battery)
 - 1) whenever the machine is left unattended;
 - 2) before clearing a blockage;
 - 3) before checking, cleaning or working on the machine;
 - 4) after striking a foreign object;
 - 5) whenever the machine starts vibrating abnormally.
- Always ensure that the ventilation openings are kept clear of debris.

Maintenance and storage

- Disconnect the machine from the power supply (removable battery) before carrying out maintenance or cleaning work.
- Use only the manufacturer's recommended replacement parts and accessories.
- Inspect and maintain the machine regularly. Have the machine repaired only by an authorised repairer.
- When not in use, store the machine out of the reach of children.

Service:

- Do not use the leaf blower if the switch does not turn it on or off. Any power tool that cannot be controlled by the switch is dangerous and must be repaired or replaced.
- Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the leaf blower's operations. If damaged, have the power tool repaired or replaced.
- Before using the machine and after any impact, check for signs of wear and damage and repair or replace as necessary.
- Always ensure that the ventilation openings are kept clear of debris.
- Have your leaf blower serviced by a qualified repair person using only genuine replacement parts. This will ensure that the safety of the leaf blower is maintained.
- Do not attempt to repair any damaged parts on the leaf blower unless you are qualified to do so.

Intended Use:

- This product is intended for DOMESTIC USE ONLY.

Warning Label Descriptions



Read instruction manual before use



Remove battery after use.



Wear eye protection when using this product.



Keep hair and loose clothing away from moving parts.



General hazard safety alert.



Wear ear protection when using this product.



Keep bystanders 5m away.



Do not use in rain or leave outdoors when raining.



Guaranteed sound power level.


Thank you for choosing a Gtech Leaf Blower

“I started Gtech to create sensible, easy to use products, which do a great job. Your opinion is important to us. Please take the time to write a review of your new Leaf Blower at [Trustpilot.co.uk](https://www.trustpilot.co.uk). We will use your feedback to improve our products and services and let other people know what it’s like to be part of the Gtech family.”


Nick Grey – Inventor, Owner of Gtech

What’s in the box


- 1 Leaf blower main body
- 2 Leaf blower nozzle




Assembly




Align the bayonet on the nozzle to the marker on the main body.



Push the nozzle over the marker and twist the nozzle clockwise over the bayonet.




The nozzle will click into place once secured.




Insert the battery in the cradle and push until it clicks into place.

Operation




To operate the leaf blower hold the handle firmly and press the trigger with your forefinger.




To stop the leaf blower, release the trigger.

Modes




The leaf blower has variable power depending on the amount of pressure applied to the trigger. To provide more power, apply more pressure to the trigger.




To provide less power to the leaf blower, apply lighter pressure to the trigger.

Removing the Battery



To remove the battery push the release lever in the handle to unlock the battery.




Then remove the battery from the cradle by the handle.




WARNING:

Do not store the battery outside for prolonged periods of time over the winter months.

Charging




Place the battery onto the charging unit. Plug in the charger and switch it on.



While charging, the LEDs will progressively pulse until all four are lit. When the battery is fully charged the LEDs will turn off and the charger LED will flash. This should take up to 5 hours.

State of charge



To find out how much charge there is in the battery press the button in the centre of the state-of-charge display. The number of lit LEDs shows the charge.

Product Care

To ensure that your Leaf Blower gives you long and reliable service, carry out the following maintenance regularly:

- Check for obvious defects such as loose or dislodged fixings and worn, damaged or loose parts.
- Check that covers and guards are correctly fitted and undamaged.
- Always clean after use.
- Do not use water, solvents, or polishes to clean the leaf blower. Wipe clean with a dry cloth.
- Do not use abrasive materials to clean the product, and do not immerse it in water.
- Store in a secure, dry place, out of reach of children. Do not expose to moisture.

PLEASE NOTE: If the product needs to be repaired or replaced only use replacement parts supplied by the manufacturer.

Spare parts can be purchased from Grey Technology Ltd:
tel : **01905 345 891** www.gtech.co.uk



WARNING: Risk of electric shock. Pay attention to the position of garden cables.



WARNING: To reduce the risk of personal injury always wear eye protection. Personal protective equipment such as sturdy gloves and non-slip shoes are recommended.



Pay attention to the hazard posed to third parties from the increased working area of the leaf blower.



Always take care when other people are around you. The leaf blower may blow out stones and debris at high speed.

Troubleshooting

Leaf Blower fails to operate	<ol style="list-style-type: none"> 1. Recharge battery. 2. Check switch. It will click if operating correctly. 3. Motor is jammed
Blowing time has reduced	Fully discharge and recharge battery.
Abnormal vibrations	Check the nozzle is securely screwed on.
Leaf Blower stops when in use	<ol style="list-style-type: none"> 1. Wait for automatic cut out to reset. 2. Check nozzle and remove any debris. 3. Charge battery.
Charger flashing red (slow)	Battery too hot. Allow to cool.
Charger flashing red (rapid)	Battery fault. Call Gtech.
<p>If this doesn't solve your problem don't worry, we will help. Go to www.gtech.co.uk or call 01905 345 891</p>	

GTECH LEAF BLOWER TECHNICAL SPECIFICATION

Voltage	36V
Battery capacity	4 Ah Li-Ion
Charge time	5 hours
Measured sound power level	102.2 dB(A)
Declared sound power level	104 dB(A)
Sound pressure level	90.6 dB(A)
Vibration	1.75m/s ² K=1.5m/s ²
Weight	4.3kg
Charger INPUT	100V-240V~50/60 HZ 50W
Charger output voltage	42V DC ---- 1A

WARRANTY – TERMS AND CONDITIONS

If your Gtech Leaf Blower breaks during the first 2 years, don't worry, we will mend it for you.

Go to www.gtech.co.uk/support or call 01905 345 891 for assistance.


WHAT ISN'T COVERED

Gtech does not guarantee the repair or replacement of a product as a result of:

- Normal wear and tear.
- Accidental damage, faults caused by negligent use or care, misuse, neglect, careless operation or handling of the leaf blower which is not in accordance with the leaf blower operating manual.
- Use of the leaf blower for anything other than normal domestic garden purpose.
- Use of parts and accessories which are not Gtech genuine components.
- Faulty installation (except where installed by Gtech).
- If it is modified in any way.
- Repairs or alterations carried out by parties other than Gtech or its authorised agents.
- If you are in doubt as to what is covered by your warranty, please call the Gtech Customer Care Helpline on 01905 345 891.

SUMMARY

- The guarantee becomes effective at the date of purchase (or the date of delivery if this is later).
- You must provide proof of delivery/purchase before any work can be carried out on the leaf blower. Without this proof, any work carried out will be chargeable. Please keep your receipt or delivery note.
- All work will be carried out by Gtech or its authorised agents.
- Any parts which are replaced will become the property of Gtech.
- The repair or replacement of your leaf blower is under guarantee and will not extend the period of guarantee.
- The guarantee provides benefits which are additional to and do not affect your statutory right as a consumer.

The  symbol indicates that this product is covered by legislation for waste electrical and electronic products (EN2002/96/EC)

When the product has reached the end of its life, it and the Li-Ion battery it contains should not be disposed of with general household waste. The battery should be removed from the product and both should be disposed of properly at a recognised recycling facility.

Call your local council, via amenity site, or recycling centre for information on the disposal and recycling of electrical products. Alternatively visit www.recycle-more.co.uk for advice on recycling and to find your nearest recycling facilities.

FOR HOUSEHOLD USE ONLY



Gtech

Grey Technology Limited

Brindley Road, Warndon, Worcester WR4 9FB

email: support@gtech.co.uk

telephone: 01905 345891

www.gtech.co.uk