Attaching the battery

Sit the battery in the base of the battery cradle, located on the down tube. Make sure that the green power button is facing outwards, away from the down tube.

Push the battery firmly down towards the frame. It will click when it is in place.

To lock the battery into place for security, first remove the rubber lock cover.

Insert the battery key into the lock and turn clockwise to lock the battery in place. Replace the rubber lock cover.

Once locked, the battery carry handle will not move and you will not be able to remove the battery from the cradle without unlocking it.

Removing the battery

If you have locked your battery in place, you must unlock it before trying to remove it from the battery cable:

To unlock the battery, first remove the rubber lock cover.

Insert the battery key into the lock and turn anti-clockwise to unlock the battery. Replace the rubber lock cover.

To remove the battery, squeeze the green trigger, while pulling the carry handle upwards to release the battery from the cradle.

Pull the battery away from the frame to remove it.

Once locked, the battery carry handle will not move and you will not be able to remove the battery from the cradle without unlocking it.

Charging the battery



When the lights rapidly cycle red, recharge the battery.

1. You can charge the battery while it is still attached to your eBike.
2. Plug the charger into the wall, then remove the rubber charging point cover and connect the charger to the battery.

Alternatively, you can remove the battery from your eBike. Plug the charger in and connect it to the battery.

After 3 hours the LEDs turn green and charging is complete.

Always fully charge your battery before storing. For optimum performance, we recommend that you store the battery indoors during the winter months.

Turning your eBike on

Your battery has three power settings – Power 1, Power 2 and Off.

Press the power button on your battery.

The LEDs will light up to show how much charge is in the battery. Your battery is now on Power 1 setting.

To switch to Power 2 setting, simply press and release the power button again.

To turn the battery off, briefly press and then release the green power button on your battery.

If you do not turn off your battery before removing it from your eBike it will power down after 2 minutes.

You can still check how much charge is left in your battery when it is not attached to the bike. Briefly press the green power button to display the level of charge.